

Starting and using your Composting Toilet

Starting your Unit

1. Add 10-15cm of bulking agent to your chamber - evenly layered - you can start using your toilet now
2. 2-4 days later add ½ packet of Nature Quick Microbes mixed with warm water to the chamber via the pedestal
3. 7-10 days later add the second ½ packet of Nature Quick Microbes mixed with warm water to the chamber via the pedestal - your system is now fully activated with live bacteria
4. Repeat these steps each time you start a chamber.

Things to do on each visit to your Composting Toilet

1. After urinating, do nothing except close the lid
2. After every solid -
 - 2.1. Add a handful (250ml) of bulking agent into the system via the pedestal
 - 2.2. Add 10-12 squirts of the diluted Nature Flush Enzymes via the pedestal - this assists the bacteria in breaking down the newly introduced waste
 - 2.3. Close the lid

Cleaning and Maintaining your System

1. Cleaning the inside of your pedestal use the diluted Nature Flush Enzymes and toilet brush - **DO NOT USE CHEMICALS**
2. Cleaning the outside of your pedestal use a mild detergent or diluted white vinegar
3. For CM LP; CM HP units rotate the mixer arm each week to aid in lengthening the time a chamber can be in use, other systems please consult your manual
4. Every 6 months spray your fan with WD 40 to extend the lifespan of your fan (this helps loosen any dirt etc.. in the ball bearings)

Tips

1. Carry a spare fan
2. Check your excess fluid hose for blockages, periodically
3. Keep your pile at 60% moisture content (best for composting)

